





aranet
by SAF Tehnika




Aranet Gateway Pro

Quick start guide

In the box:



Aranet Gateway Pro




Wall-mount screws



Quick Start Guide


Placement options:

A) on flat surface




B) mount it on a wall


1. Remove the back disk from the device



2. Mount the back disk to the wall




3. Attach the gateway to the mounted disk




Power options:

A) USB-C power adapter*




B) PoE injector *



*Not included—available separately on aranet.com

C) or use your existing PoE switch




Follow through setup wizard to connect your Gateway to internet, Aranet Cloud and pair your sensors.





aranet
by SAF Tehnika



Scan the QR code to see
Aranet Gateway Pro user guide

Aranet Gateway Pro user guide

help.aranet.com/gateway

©SAF Tehnika JSC
All rights reserved. V1.0

aranet.com